# STOP GLOBE VALVE ACID-PROOF TYPE ZSA320

## **CHARACTERISTIC:**

Diameter	-	10 -100 mm;
Pressure	-	320 bar;
Temperature	-	up to 250°C for acids, bases and other aggressive media;
	-	up to 550°C for non-toxic media; (with PTFE sealing up to 200°C);
Medium	-	acids, liquors, water, steam and other non-toxic and non aggressive liquid and
		gas media, engine fuel.

# **VERSIONS:**

#### type / ends / body material / disc and disc ring / drive type Example: ZSA320 / --- / ---

Example:	ZSA320 / / /
Example:	ZSA320 / SW / L /

		EXU	inpic.	LOADED	/ • /				
Type - body material	Sign	Ends Sign		Disc and disc ring	Sign	Others	Sign	Drive type	Sign
X6CrNi18-10 or GX5CrNi19-10	ZSA320	Standard - BW		Standard				Hand wheel	
X2CrNiMo17-12-2 or GX5CrNiMo19-11-2	ZSB320	Socket weld Flanged	SW K	Stellit	L	Indicator	x	AUMA Drive NWA Drive	NA NW
								MODACT Drive	NM

# **APPLICATION:**

Stop globe valve (**ZSA320**) is designed to open and stop the flow. The valve is not supposed to be used as a regulating device. For regulation the version with throttling plug should be applied.

DN 10 ÷ 15

#### DN 20 ÷ 50

#### DN 65 ÷ 100



LRQA CERTIFIED

# FABRITKA ARMATORT PRZEMTSŁOWIWAKMET Sp. z o.o.Bodzanów 7548-340 GŁUCHOŁAZYtel.+48 77 439-40-20, fax +48 77 439-18-72wakmet@wakmet.com.plwww.wakmet.com.pl

# MATERIALS:

Version	ZSA320	ZSB320	ZSA320	ZSB320	ZSA320	ZSB320					
Parts	DN	10 - 25	DN	32 - 50	DN 65 - 100						
Body	X6CrNiTi18-10 (1.4541)	X2CrNiMo17-12-2 (1.4404)	X6CrNiTi18-10 (1.4541)	X2CrNiMo17-12-2 (1.4404)	X6CrNiTi18-10 (1.4541)	X2CrNiMo17-12-2 (1.4404)					
Bonnet	X6CrNiTi18-10 (1.4541)			GX5CrNi19-10 (1.4308)	X6CrNiTi18-10 (1.4541)	X6CrNiTi18-10 (1.4541)					
Disc					X6CrNiTi18-10 (1.4541)	X2CrNiMo17-12-2 (1.4404)					
Stem	X6CrNiTi18-10 (1.4541)	X2CrNiMo17-12-2 (1.4404)	X6CrNiTi18-10 (1.4541)	X2CrNiMo17-12-2 (1.4404)	X6CrNiTi18-10 (1.4541)	X2CrNiMo17-12-2 (1.4404)					
Packing rings, gasket	Graphit										
Wheel	Cast Iron										

Special materials on request; modifications reserved.

### **DIMENSIONS:**

DN	d	Dz	Dw	L	Weight	Н	h	Dk	
10	10	20	12	100	0.00	005	12	140	
15	14	22	15	160	2,90	205		140	
20	20	28	19	160	7.00	220	10	000	
25	24	35	24	160	7,20	266	19	200	
32	30	44	31,5						
40	38	50	36	300	29,50	418	23	360	
50	44	77	59,5						
65	62	91	68	340	41,00	714	45	GNR 700	
80	76	117	87,5	380	83,00	637	36	GNR 500	
100	<b>00</b> 92 144		109,5	430	125,00	720	50	GNR 500	

Dimensions in mm; modifications reserved.

# **TECHNICAL DATA:**

		PN						Nominal	working	pressur	e at worl	king tem	perature	l.				
Body material	Medium	FIN	20°C	100°C	150°C	200°C	250°C	300°C	350°C	400°C	450°C	480°C	500°C	510°C	520°C	530°C	540°C	550°C
		bar																
X6CrNiTi18-10 (1.4541)	Aggressive media 320	320	320	317	299	283	270	-	-	-	-	-	-	-	-	-	-	-
GX5CrNi19-10 (1.4308)		320	305	244	217	190	179	-	-	-	-	-	-	-	-	-	-	-
X6CrNiTi18-10 (1.4541)	Aggressive	320	320	317	299	283	270	254	245	238	232	230	227	226	226	225	224	216
GX5CrNi19-10 (1.4308)		320	305	244	217	190	179	168	156	145	133	128	122	-	-	-	-	-
X2CrNiMo17-12-2 (1.4404)	Aggressive 32	320	320	320	312	297	293	-	-	-	-	-	-	-	-	-	-	-
GX5CrNiMo19-11-2 (1.4408)	media	320	320	259	232	205	190	-	-	-	-	-	-	-	-	-	-	-
X2CrNiMo17-12-2 (1.4404)	Non	320	320	320	312	297	293	276	265	257	250	247	244	243	243	242	242	242
GX5CrNiMo19-11-2 (1.4408)	Aggressive media	320	320	259	232	205	190	175	167	160	155	154	153	-	-	-	-	-

# **MOUNTING AND OPERATING:**

The valve can only be mounted and operated by skilled, properly trained and qualified personnel. Incorrect assembly or operation of the valve may have substantial impact on the entire system such as fluid leakage, reduction in system's function etc.

Before a valve is installed the pipeline must be clean from any mechanical impurities. The compatibility of critical parameters of the flow must be checked with the parameters of the valve. Stop globe valve can be mounted to a pipe-line in any position. The direction of flow should only comply with the arrow marked on the body. The valve should be operated strictly with its assign. In order to provide valve's reliability the following suggestions must be observed:

- medium flowing through the valve is supposed to be clean out of any mechanical impurities;
- the valve must be protected from any mechanical damages during its work;
- nominal parameters marked on the valve must be observed.