STOP GLOBE VALVE TYPE ZA420

CHARACTERISTIC:

Diameter - 6 -10 mm;	
Pressure - 420 bar;	
	and other aggressive media;
up to 550°C non-toxic and no Medium - acids, liguors, water, steam a	and other non-toxic and non aggressive media.

VERSIONS:


type body material / ends / disc and disc rings / others

Example: ZA420 / --- / --- /---

		Example:	ZB42	20 / / 1 / ·				
Type body material	Sign	Ends	Sign	Disc and	disc rings	Sign	Others	Sign
X6CrNiTi18-10	ZA420	Standard		Standard	X17CrNi16-2 (450°C) X22CrMoV12-1 (550°C)			
X2CrNiMo17-12-2	ZB420			Tytanic BT-	-9	Т		

APPLICATION:

Stop globe valve is designed to open and stop the flow. The valve is not supposed to be used as a regulating device.





MATERIALS:

Version	Z	4420		ZB420								
	Aggressive media	Non Aggressive	nedia Agg	ressive media	Non Aggressive media							
Parts	Т _{мах} 250 ⁰ С	Т _{мах} 550 ⁰ 0	с т	_{мах} 250 ⁰ С	Т _{мах} 550 ⁰ С							
Body, bonnet	X6CrNiTi1	8-10 (1.4541)		X2CrNiMo17	-12-2 (1.4404)							
Seat ring			-									
Disc	T _{MAX}	450 [°] C		Т _{мах} 550 ⁰ С								
	X17CrNI16-	2 (1.4057) / BT9		X22CrMoV12-1 (1.4923) / BT9								
Stem		T _{MAX} 450 [°] C - 550 [°] C										
Stem		X22CrMoV12-1 (1.4923) / BT9										
Packing rings		Graphit										
Wheel		Cast iron										
Butt weld ends	P250GH	16Mo3	13CrMo4-5	X6CrNiTi18-	10 X2CrNiMo17-12-2							

Special materials on request; modifications reserved.

DIMENSIONS:

DN	Do	Dw	Dz	L	Н	h	Dk	Weight
6	6	8,4	10,2	120	102	5	60	0,70
8	8	10,4	12,0	120	102	5	60	0,70
10	9,6	12,0	13,7	120	102	5	60	0,70

Dimensions in mm; modifications reserved.

TECHNICAL DATA:

		PN		Maximal working pressure at working temperature														
Body material	Medium	FIN	20°C	100°C	150°C	200°C	250°C	300°C	350°C	400°C	450°C	480°C	500°C	510°C	520°C	530°C	540°C	550°C
			bar															
X6CrNiTi18-10 (1.4541)	aggressive	420	420,0	415,9	391,9	371,9	353,9	-	-	-	-	-	-	-	-	-	-	-
X2CrNiMo17-12-2 (1.4404)	media	420	420,0	397,9	362,0	333,9	313,9	i	-	-	-	-	-	-	-	-	-	-
X6CrNiTi18-10 (1.4541)	non	420	420,0	415,9	391,9	371,9	353,9	333,9	321,9	311,9	304,8	301,3	297,9	294,0	291,9	288,7	285,6	283,8
X2CrNiMo17-12-2 (1.4404)	aggressive media	420	420,0	397,9	362,0	333,9	313,9	289,9	277,9	269,9	262,9	259,1	255,9	255,9	255,9	254,9	254,9	254,9

MOUNTING AND OPERATING:

The valve can only be mounted and operated by skilled, properly trained and qualified personnel. Incorrect assembly or operation of the valve may have substantial impact on the entire system such as fluid leakage, reduction in system's function etc.

Before a valve is installed the pipeline must be clean from any mechanical impurities. The compatibility of critical parameters of the flow must be checked with the parameters of the valve. Stop globe valve can be mounted to a pipe-line in any position. The direction of flow should only comply with the arrow marked on the body. The valve should be operated strictly with its assign. In order to provide valve's reliability the following suggestions must be observed:

- medium flowing through the valve is supposed to be clean out of any mechanical impurities;
- the valve must be protected from any mechanical damages during its work;
- nominal parameters marked on the valve must be observed.