# STOP GLOBE VALVE TYPE 673

# **CHARACTERISTIC:**

Diameter - 15 -100 mm; Pressure - 250 bar; Temperature - up to 670°C;

Medium - water, steam and other non-toxic, non aggressive liquid and gas media.

**VERSIONS:** type / ends / body material / disc and disc ring / drive type

Example: 673 / --- / --- / --- / --- Example: 673 / K / U / L / ---

Sign
SW
K


Body material	Sign
(P250GH) C 22.8	
16Mo3	U
13CrMo4-5	Α
11CrMo9-10	В
14MoV6-3	С
X10CrMoVNb9-10	Е

Disc and disc ring	Sign
Standard	
Stellit ring	L

Drive type	Sign
Hand wheel	
AUMA drive	NA
NWA drive	NW
MODACT drive	NM
Pneumatic drive	NP

## **APPLICATION:**

Stop globe valve with throttle plug is designed to open and stop the flow. The valve is supposed to be used as a regulating device.





R FABRYKA ARMATURY PRZEMYSŁOWEJ

WAKMET Sp. z o.o.

**Bodzanów 75 48-340 GŁUCHOŁAZY** tel.+48 77 439-40-20, fax +48 77 439-18-72

 $\underline{wakmet@wakmet.com.pl}$ 

www.wakmet.com.pl

#### **MATERIALS:**

Versions	Standard	U	Α	В	С	E					
Parts	T <sub>MAX</sub> 450°C	T <sub>MAX</sub> 450°C		T <sub>MAX</sub> 600°C	T <sub>MAX</sub> 570°C	T <sub>MAX</sub> 670°C					
Body	(P250GH) C22.8	16Mo3	13CrMo4-5	11CrMo9-10	14MoV6-3	X10CrMoVNb9-10					
Войу	(1.0460)	(1.5415)	(1.7335)	(1.73813	(1.7715)	(1.4903)					
Bonnet	DN 15-25	<b>DN 15-25</b> 13CrMo4-5 (1.7335) <b>DN 32-125</b> G17CrMo5-5 (1.7357) 11CrMo9- (1.7383									
Stem DN 15-65		X39C	rNi17-1 (1.4122),	X22CrMoV12-1	(1.4923)						
Disc DN 80-125	11CrMo9-10 (1.7383)	11CrMo9-10 (1.7383)	11CrMo9-10 (1.7383)	11CrMo9-10 (1.7383)	11CrMo9-10 (1.7383)	X10CrMoVNb9-10 (1.4903)					
Seat ring			BT9	or Stellit							
Upper stem		X17CrNi16-2 (1.4057), X39CrNi17-1 (1.4122)									
Wheel		Cast iron									

Special materials on request; modifications reserved.

## **DIMENSIONS:**

	S	tandard – Butt weld	ends				<b>L</b>	Die	
DN	d	Dz	Dw	L	Weight	Н	h	Dk	
10	10	20	12	100	2.00	205	10	140	
15	14	22	16	160	2,90	205	12	140	
20	20	28	19,5						
20	18	20	19,5	160	7,50	266	19	200	
25	24	35	26,5						
32	30	44	32,5						
40	38	50	50 38,5		30,50	418	23		
40	36	50	30,3	300				360	
50	44	62	45						
30	42	02	45						
65	62	77	E0 E	340	42,50	714	45	GNR 700	
00	56	11	59,5	340	42,50	/14	45	GINA 700	
80	76	117	93	380	85,00	637	36	GNR 500	
100	92	144	116,5	430	127,00	720	50	GNR 500	

Dimensions in mm; modifications reserved.

### **TECHNICAL DATA:**

			••															
	PN						М	aximal w	orking pr	essure a	t workin	g temper	ature					
Body material	FIN	20°C	100°C	150°C	200°C	250°C	300°0	350°C	400°C	450°C	480°C	500°C	520°C	530°C	540°C	560°C	570°C	600°C
•									b	ar								
(P250GH)C 22.8 (1.0460)	250	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	165,0	-	-	-	-	-	-	-	-
<b>16Mo3</b> (1.5415)	250	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	222,0	176,0	141,0	112,0	-	-	-	-
<b>13CrMo4-5</b> (1,7335)	250	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	224,0	186,0	146,0	95,0	79,0	-
<b>14MoV6-3</b> (1.7715)	250	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	205,0	174,0	-
11CrMo9-10 (1.7383)	250	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	250,0	246,0	215,0	186,0	138,0	122,0	81,0
	PN						М	aximal w	orking pr	essure a	t workin	g temper	ature					
Body material	PN	20°C	530°	C 540°	°C 550	0°C 56	60°C 5	70°C 5	80°C 5	90°C (	000°C	610°C	620°C	630°C	640°C	650°C	660°C	670°C
									b	ar								
X10CrMoVNb9-1 (1.4903)	250	250,0	250,	,0 250	,0 25	0,0 25	50,0 2	250,0 2	250,0 2	250,0	224,0	198,0	174,0	155,0	134,0	117,0	100,0	86,0

## **MOUNTING AND OPERATING:**

The valve can only be mounted and operated by skilled, properly trained and qualified personnel. Incorrect assembly or operation of the valve may have substantial impact on the entire system such as fluid leakage, reduction in system's function etc.

Before a valve is installed the pipeline must be clean from any mechanical impurities. The compatibility of critical parameters of the flow must be checked with the parameters of the valve. Stop globe valve can be mounted to a pipe-line in any position. The direction of flow should only comply with the arrow marked on the body. The valve should be operated strictly with its assign. In order to provide valve's reliability the following suggestions must be observed:

- medium flowing through the valve is supposed to be clean out of any mechanical impurities;
- the valve must be protected from any mechanical damages during its work;
- nominal parameters marked on the valve must be observed.